



Use 2n3904/06 transistors or similar.  
 Use 1n914 diodes or similar.  
 Transistor orientation on the silkscreen is EBC.  
 For the "freq" and "freq2" nodes, use a pot as a voltage divider and then have a 100k from the clockwise node on the pot going to the FM input.

